


24 ROW TO 23 ROW REDUCER INSTALLATION GUIDE




K002232 - Kit - Row Reducer Gen I 24 Row to 23 Row HO Meter


Item No.	Qty	Part Number	Description
1	1	M000154	Row Reducer 12 Row - HO Outside
2	1	M000179	Cap - 2-1/2" Orange w/Hole
3	1	P000240	Hose Clamp - 2" S/S




24 ROW TO 23 ROW REDUCER INSTALLATION GUIDE



APPLY SILICONE TO TOP OF AUGER COVER (ARROW 1).
REDUCER SHOULD BE TIGHT AGAINST THE SIDE OF THE METER,
BELOW THE BOLTS THAT HOLD THE BEARING IN PLACE
(ARROW 2). SNAP THE REDUCER DOWN OVER THE COVER.



WITH THE REDUCER SECURELY IN PLACE, SEAL EACH EDGE WITH SILICONE. REPEAT FOR EACH REDUCER.



SLIDE CAPS OVER ALL BLOCKED ROW OUTLET TUBES. SECURE EACH ONE WITH A HOSE CLAMP.

