




12- Row Gladiator Hose Routing For 6 Ton Montag Dry Fertilizer Skid




16- Row Gladiator Hose Routing For 6 Ton Montag Dry Fertilizer Skid



Route hoses under the center cylinder lug.




Center hoses will go under the back tube and over the second tube of Montag's skid.




16 ROW	<u>1</u>	<u>2</u>	<u>3</u>	<u>4</u>	<u>5</u>	<u>6</u>	<u>7</u>	<u>8</u>	<u>9</u>	<u>10</u>	<u>11</u>	<u>12</u>	<u>13</u>	<u>14</u>	<u>15</u>	<u>16</u>
	29'	27'4"	24'8"	22'4"	19'6"	18'6"	14'6"	13'8"	13'8"	14'6"	18'6"	19'6"	22'4"	24'8"	27'4"	29'

Hose lengths



Assemble hose support straps to the cast clamp bolts so that the hoses can move forward when tripping over a rock. The center hose supports need to be extended farther back than the wings.



Use qty (4) 1/2" nuts and flat washers to mount U-bolts


MonTag / Gladiator Row Unit Assembly Instructions

Hose routed around the outside of springs as shown.

Montag supplied: 3" Exhaust hose and hose clamps



Montag supplied air release mount bracket – M004788

6 Row Mount Kit – Q1024330
8 Row Mount Kit – Q1024340
12 Row Mount Kit – Q1024350
16 Row Mount Kit – Q1024360
24 Row Mount Kit – Q1024370



Montag supplied 1.5" hose & clamps or optional blockage sensor (shown)

Kuhn supplied drop tube



MonTag / Gladiator Row Unit Assembly Instructions

**No hose clamp
on upper end
to allow for
shank
adjustment**

Kuhn supplied hose
clamp




MonTag / J. Assy / Gladiator Blockage Sensor Assembly Instructions

Install couplers as shown. It is important to keep couplers in line with air release and hose as shown. Refer to J. Assy install guide for setup and programming of monitor and sensors.


Clamp coupler over air release.

P002397
1-1/2" x 1-1/2"
Blockage Sensor.


Wireless antenna is under the words "J.ASSY" - orient for the least steel interference between antenna and monitor.

Clamp coupler over s/s drop tube

You will want to have the "digital" section of the sensor orientated for easy access when programming. This area is used to label the row number that this sensor is attached to.







Sensor Kits

- 6 Row – Q1024970
- 8 Row – Q1024910
- 12 Row – Q1024920
- 16 Row – Q1024930
- 24 Row – Q1024950



HYDRAULIC COMPONENTS FOR MONTAG GEN I DRY SKID*



Install hoses in A000109/A000177 from tractor to corresponding ports shown:

Hookup case drain alarm to 12VDC power.

A000109:
8-12 Row – ½” Lines
(See Hydragrip color coordination).

A000177:
16 Row - ¾” hoses are for pressure and return.
½” hose is for the zero-pressure case drain.

* Hookup locations for a single section machine.

Mounting For 6 Ton Montag Dry Fertilizer Skid

Make sure the long side of the Cart Sub Frame is facing the rear of the Gladiator. Mount the Tank Skid so that the ends are flush with the ends of the Cart Sub Frame. Use the 5/8 NC x 4 U-bolts or weigh bars provided by Montag to clamp Tank Skid to Cart Sub Frame.

